

cutout holes in doubler panel for servos, radio and battery
glue or double side the panel down so the edge is about 5mm away from the wing fold
double side the servos down and hold in place with tie wraps
mount the battery as far forward as you can but leave little room for a foam block in front of the battery

daz 6/4/2002

dazb@zip.com.au

